

## CONSOLE CONNECTOR KIT 7850

# INSTALLATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS

FOR USE WITH: Various Two-channel Organs LESSIE Speaker Models 705, 705C, 720

#### KIT CONTENT

Console Connector 138488 Switch Assembly, Cable Assembly, 11-conductor, 30-foot 137357

Hardware Package 137356 Oiler\* 05302

\*\*CAUTION: Due to the presence of electrical potential\*\*

Location: Due the da presence or electrical potential, installation procedures mechanical parts, installation procedures the procedure caping work inside the LESLIE speaker cabinet or the organ console should be performed only by service personnel authorized by the dealer or factory to perform south work.

INSTALLATION

CAUTION: DISCONNECT ORGAN POWER BEFORE PROCEEDING!

NOTE: Read the instructions completely through before beginning actual installation.

### CONTROL UNIT MOUNTING (figures 1, 2)

- Select a location under the keyboard shelf where the control is to be mounted, either left or right, as the organist prefers.
- The plug on the control cable must pass into the interior of the organ. If no hole is available, use a hole saw to make a 1-inchdiameter hole.
  - CAUTION: BE CAREFUL TO SELECT A LOCATION WHERE NO INTERNAL COMPONENT OR WIRING WILL BE DAMAGED WHEN THE HOLE IS MADE.

NEVER USE THE OIL ON THE HEARINGS OF THE ROTCE. These bearings are treated at the factory with a special type of lubricant, and application of any other type of lubricant may be detriented to the operation of the rotor. The oil included in this kit is to be used only for oiling the motor of the LESLIE speaker.

- Indicate the control location on the under side of the shelf. Cut out the paper template (figure 2) provided in this instruction sheet.
- 4. Measure the width of the key strip at the place chosen for control mounting. Fold the template along the line corresponding to this width. If the keybed is flat (no separate key strip) do not fold the template at all.
- Lay the semplate in position behind the key strip with the narrow portion toward the front of the organ; and use a sharp instrument or pencil to scribe the location of the four mounting screws. Start the holes for the screws.

NOTE: To retain maximum screw-holding power, merely break the surface of the wood.

6. Put the four leveling screws (flat-headed machine screws) into the holes indicated in figure 2, WITW INTE HEADS UPWARD. Hold the control mounting bracket in position at the location marked for mounting. Adjust each of the four leveling screws so that the control is positioned just below the keybed, and is level. See figure 1.

NOTE: Be sure the control switch handles do not protrude too much.

- Selectione set of four mounting screws which are sufficiently long to fasten the control to the organ but no so long as to damage internal wiring or components.
- Fasten the mounting screws into the keyboard shelf in the locations previously marked.
- Route the control cable through the hole prepared for it and through the organ into the area near the back panel.

#### CONSOLE CONNECTOR

This kit will generally be used with organs having two independent channels; that is, two separate amplifiers feeding two loudspeaker systems.

Frequently, one of the speaker systems includes a rotor or a rotating speaker, such as a built-in LESSIE trempol unit. This system is generally used to reproduce the flute of "full" volces of the organ rotating speaker it may have an electronic trempol, particularly for use with the "tibia" volces. The signals normally fed to the speaker system handling these voices (or having the rotating unit) should be schematic.) The signals are returned to the organ after being picked up in the switch assembly for routing to the rotary channel of the LESSIE speaker cabinet. The term "fulle/tibia" is used hereafter in signal, etc.). a System or its components (i.e., speaker, maplifier, signal, etc.).




Figure 1. Control Mounted on Organ




Figure 2. Control Location and Mounting Template

a second system in an organ for which this kit is applicable usually has a 12- or 15-inch speaker to handle the pedal and bass range, and sometimes may have other speakers connected in parallal as well. Signal originating in this system should be connected to as well. Signal originating in this system should be connected to the stationary channel of the LESILE speaker cobinet. The term "main" is used hereafter in reference to this system or its components.

In some organs one or the other of these systems (or, sometimes, both consists of more than one speaker, with a crossover or dividing network separating the speakers. In such cases, the organ circuit must be interrupted so that the input wire of the console connector is commerced to the organ amplifier for the system and the return or dividing network.

Occasionally the crossover network component(s) in the organ will be mounted and wired integrally on the amplifier printed circuit board or assembly. In these cases there will usually be separate wires connecting the amplifier to each speaker. The console connector input wire for the channel involved should be connected to the amplifier signal wire feeding the speaker considered to be the most important, leaving the secondary speaker permanently wired to the dropen. Of the settlem of the control unit ORGAN/MIX/EDIG witch.

(Cut out template on opposite side)

#### CONSOLE CONNECTOR MOUNTING

Choose a location for the console connector in the area of the back panel, or other suitable place where the chassis can be firmly fastened and will not touch other components.

If it is intended that pluy-in connection to the LESLIE speaker shall be made through the back panel of the organ, a mittable boile must be provided and the console connector mounted in such a way that is not located adjacent to the back panel the connecting calle, after being attached to the l1-contact socket, must pass through a hole or control or the control of the control of

If the console connector is to be mounted for direct plug-in, as described above, choose a untable location with sufficient clearance for attachment of all plugs and sockets and where the licentact socket can be flush with the back panel. Using a hole saw or other suitable equipment, make a 1-3/4-inch-diameter hole in the back panel, centered exactly on the socket.

Using 1/2-inch-long sheet metal screws provided in this kit,




Figure 3. Interconnections, Two-speaker Organ

Figure 4. Interconnections When Dividing Network is Present

# CONSOLE CONNECTOR WIRING

NOTE: The wires which connect to the organ circuits terminate in male or female tab connectors which fit directly to standard speaker terminals. If the wires to the speakers are soldered on, a limit of the wind of the speakers are soldered on, a limit of the wind of the

Whichever method is selected, cut the tab connector from the end of the wire, strip 1/8-inch, and make the connection either by soldering the wire to the speaker terminal or using a wire nut to attach the appropriate wires to gether. In cutting wires in the strip of the strip o

The brown and orange wires are for channel 1 and the red and yellow for channel 2 of the console connector.

- 1. Connect the black wire to the organ "main" speaker ground.
- Remove the signal wire from the "main" speaker in the organ; attach it to the RED wire from the console connector.
- 3. Attach the YELLOW wire to the speaker terminal just vacated. (If the wires in the organ are cut, connect the side that is still attached to the amplifier to the RED wire from the console connector. Connect the wire attached to the speaker to the YELLOW wire.
- Remove the signal wire from the "flute/tibia" speaker in the organ; attach it to the BROWN wire from the console connector
- 5. Attach the ORANGE wire to the speaker terminal just vacated. (If the wires in the organ are out, connect the side that is still attached to the amplifier to the BROWN wire from the console connector. Connect the wire attached to the speaker to the ORANGE wire.

#### FINAL PROCEDURES

- Attach the plug from the control unit to the small rectangular socket (S3) on the console connector.
- Using cable clamps, fasten the control cable to the organ frame or shelves so that it cannot move and, as far as is possible, does not touch any other wire or component.
- If the console connector has been mounted for direct pluy-in, replace the back panel of the organ and fastsm it securely in place. Connect the ll-conductor cable between the socket on the console connector and the LESLIE speaker.
- 4. If the console connector has been mounted in a position where direct connection from the outside is not possible, attach the ll-conductor cable to the console connector socket. Boute the panel; attach the cable to the shelves or floor with cable clamps so that it cannot move and, as far as is possible, does not touch any other wire or component. Replace the back panel of the organ, making sures that the cable from the console Attach the other end of the cable to the LIESLIE spaker.

#### Figure 5. Control Unit

deleted

#### CONTROLS

The control unit, mounted just below the organ keyboard, groups all the controls in one convenient location.

The center BUTTON, a push-on, push-off control, is used to actuate the LESLIE speaker system. With the button met to off, only the organ speakers operate. With the button set to on (red light glowing) the speakers in the LESLIE speaker cabinet are ready to respond.

The LEFT-HAND TOGGLE SWITCH may be set for the fast or slow effect from the LESLIE speaker rotor. Up is fagt; down is slow; center is off.

The RIGHT-HAND TOGGLE SWITCH is an ORGAN/MIX/ECHO switch. With the handle set upward only the organ speakers sound. With the handle set downward only the LESLIE speakers sound. With the handle in its center position the organ and LESLIE speakers play together (mix).

Any combination of settings may be used, to suit the musical effect desired.

The red light will help to remind you to turn the control off then you are through playing your organ.

#### Ordering Parts

Standard hardware, connectors, and electronic components should be purchased locally. Non-standard items may be obtained through a LESLIE speaker dealer. Orders should include part numbers as listed.

# PARTS LIST: 138488 CONSOLE CONNECTOR ASSEMBLY

Socket, 11-contact (S2)	028852
Housing, socket 12-circuit,	
miniature MoTex with tabs (S3)	137286
Contact, insert, miniature Molex, female	065581
Connector, tab, AMP, male	029371
Connector, tab, Berg, female	029389
Resistor, wire-wound, 100-ohm, 3W, 10% (R2, R3)	021675
Resistor, 33-ohm, 1W, 10% (R4, R5)	028332
Morminal Strip 7-lug	117990

## PARTS LIST: 137342 SWITCH ASSEMBLY

Switch and Cable Assembly	137340
Case	137282
Clamp, cable	137365
Knob, switch, white	137291
Nut, knurled	137864
Cork, adhesive	137419

#### PARTS LIST: 137340 SWITCH AND CABLE ASSEMBLY

Circuit Board Assembly	137339
Switch, lever, 3-position (TREMOLO) (SW2)	137304
Switch, lever, 3-position (ECHO) (SW1)	137305
Housing, plug, miniature Molex,	
12-circuit, natural (white) (P3)	101310
Contact, insert, miniature Molex, male	065599

#### PARTS LIST: 137357 CABLE ASSEMBLY

(contains cap body sections, screws, and tubing)			(P2)	13729 13729 13729 13745
---	--	--	------	----------------------------------



Switch, push/push (SW3)	137303
Diode, silicon, 1-amp, 100 PIV	
(D2, D3, D4)	021154
Diode, light-emitting (D1)	137315
Resistor, 47-ohm, 1/2W, 10% (R1)	016311
Etched Circuit Board	137281




Figure 8. Console Connector Interior