

LESLIE 3M ECHO CONTROL

Installation Instructions for Hammond Spinnet Organs

1. Attach control case to wood rail below lower manual, locating it beside the tremolo control case, or at the opposite end of the keyboard. Use the wood screws to mount.
2. Pass control cable into console interior. Entry may be made through the felt dust seal between the knee panel and the keyboard shelf; or, the cable may be routed underneath the console, then inside through the back opening.
3. Mount the terminal box inside the console at a convenient point, making sure that the

connecting cable will reach. Fasten the box in place with wood screws.

4. Connect the wiring exactly as shown in the diagrams below. Follow the plan which applies to organ model involved.

5. Secure the external speaker cable at the lower left corner of the console (as viewed from the back), using the clamp which is supplied. Finally, regulate the volume level, using instructions as given in the owner's manual.

