

LESLIE 038000 ADAPTER KIT INSTALLATION INSTRUCTIONS

This adapter kit allows the dealer to demonstrate from one to five Leslie Speakers from either a Lowrey or combo organ. The adapter connects either a Leslie Combo Preamp (117V-O2O875; 234/25OV-O22624) or a Lowrey Organ with 6 contact external Leslie Speaker socket to the Leslie Five Station Control Center (117V-011593; 234/250V-030270).

CONTENTS OF KIT:

Adapter 037978

Instructions 038034

TO CONNECT COMBO PREAMP TO FIVE STATION CONTROL CENTER:

1. Plug adapter into the 6 contact ""SPEAKER"" socket on the Combo Preamp. (See "A" on Fig. 1).
2. Plug Five Station Control Center cable into the adapter (See "B" on Fig. 1).
3. Adjust Combo Preamp volume controls as outlined in its service manual.
4. Turn "CONSOLE" switch on Five Station Control Center ON.



NOTE: Tremolo and Chorale modes of the demonstration Leslie(s) are now controlled by Tremolo switch on the Five Station Control Center. The Tremolo foot switch on the Combo Preamp is now inoperative.

TO CONNECT LOWREY ORGAN TO FIVE STATION CONTROL CENTER:

1. Plug adapter into the 6 contact "LESLIE" socket at the rear of the Lowrey. (See "A" on Fig. 1).
2. Plug the cable from Five Station Control Center into the adapter. (See "B" on Fig. 1).
3. Turn "CONSOLE" switch on Five Station Control Center ON.

NOTE: Depressing Lowrey "LESLIE" tab to "EXT" position turns the demonstration Leslie(s) ON. However, Tremolo and Chorale functions are now controlled by the TREMOLO switch on the Five Station Control Center. "MAIN CHORUS" and "LESLIE TREMOLO" switches on the Lowrey are now inoperative.

ORDERING PARTS: Orders should include part numbers shown above.



PLUG & SOCKET PIN LAYOUT

