

POWER RELAY 039099 KIT
INSTALLATION INSTRUCTIONS FOR USE WITH: LESLIE Speaker Models 125, 225, 145, 147

The LESLIE power relay is used to connect more than one LESLIE speaker to an organ console. The power relay provides a point of connection and a separate line voltage source for the added speaker; this prevents the additional power demand from overloading the organ power switch and cables. The relay turns the cabinet off and on with the organ.

KIT CONTENT

Power Relay Assembly, 220V 50Hz	039107
Screw, sheet metal, 8 x 1/2, Phillips head (2)	029132
Instructions	039123

CAUTION. Due to the presence of electrical potential and the danger of moving mechanical parts, installation procedures or adjustments requiring work inside the LESLIE speaker cabinet or the organ console should be performed only by a service person authorized by the dealer or factory to perform such work.


INSTALLATION

CAUTION. DISCONNECT ORGAN POWER BEFORE PROCEEDING:

1. Disconnect the cable which connects the organ and the LESLIE speaker currently in use, at the LESLIE speaker.
2. Connect the cable to the plug on the power relay chassis.
3. Connect the cable from the added LESLIE speaker to the socket on the power relay chassis.
4. Connect the socket at the end of the power relay cable to plug on the original LESLIE speaker.
5. Connect the power relay AC plug to a wall socket providing 220V 50/60Hz electrical power.

PARTS LIST: 039107 POWER RELAY ASSEMBLY

Relay, SPDT, 220V 50Hz	019299
Socket, 6-contact (S1)	060459
Cable and Socket Assembly, 6-contact (S2)	130850
Cable and Plug Assembly, 6-pin (P1)	137381
Cable, 250V, 10-foot (P2)	129950



Schematic, Power Relay Assembly 039107