

LESLIE POWER RELAY KIT # 034488
For Leslie models 251, 351, (51-50C-55C)

The Leslie Power Relay is used to connect additional Leslie Speakers to organ consoles. The power relay provides a point of connection and a separate line voltage source for the added Leslie Speaker. This prevents the additional power demand of the speaker from overloading the console power switch and cables.

Installation

1. Turn the console switch off.
2. Unplug the console cable at the existing Leslie Speaker.
3. Plug the power relay pigtail into the plug on the Leslie Speaker.
4. Plug the cable from the console into the power relay.
5. Plug the cable from the added speaker into the power relay.
6. Plug the relay power cord into a wall socket.

The new Leslie Speaker will now draw its operating power from the line through the power relay. The relay turns the cabinet off and on with the organ console, while limiting the power demand on the console.

