

LESLIE EXTRA SPEAKER ADAPTER KIT #035642

POWER RELAY KIT

FOR WURLITZER ORGANS 4300 4500 4520 USING THE 7043 KIT
TO LESLIE 125, 225 ,145, 147, 147RV, 247, 247RV

The Leslie Power Relay is used to connect additional tone cabinets to organ consoles. The power relay provides a point of connection and a separate line voltage source for the added tone cabinet. This prevents the additional power demand of the tone cabinet from overloading the console power switch and cables.

Installation

1. Turn the console switch off.
2. Unplug the console cable at the existing tone cabinet.
3. Plug the power relay pigtail into the plug on the tone cabinet.
4. Plug the cable from the console into the power relay.
5. Plug the cable from the new tone cabinet into the power relay.
6. Plug the relay power cord into a wall socket.

The new tone cabinet will now draw its operating power from the line through the power relay. The relay turns the cabinet off and on with the organ console, while limiting the power demand on the console.

