

LESLIE EXTRA SPEAKER ADAPTER KIT #034496 FOR USE WITH LESLIE SPEAKER MODELS 122, 122RV, 125, 225, 142, 145, 147, 147RV, 245, 247, 247RV

This power relay is used in multiple speaker installations. It provides a point of connection and a separate source of AC voltage for the added speaker. This prevents the additional power demand of the added speaker from overloading the organ power switch and cables.

After installation, both speakers are turned on and off by the power switch on the organ console.

KIT CONTENT

Power Relay Assembly, 117v 60Hz 022202 Screw, sheet metal, $8 \times \frac{1}{2}$, Phillips head (2) 029132 Installation Instructions 034512

 $\mbox{NOTE:}\ \mbox{The organ}\ \mbox{\underline{MUST}}\ \mbox{\underline{BE}}\ \mbox{turned}\ \mbox{off}\ \mbox{and}\ \mbox{unplugged}\ \mbox{before}\ \mbox{proceeding}\ \mbox{with}\ \mbox{installation.}$

Disconnect the interconnecting cable from the original speaker.


Attach this end of the interconnecting cable to the power relay (A, Figure 1). The other end is in the organ.
 Attach the socket end of the relay cable to the original speaker (B).

 Plug the connecting cable (part #021600 or kit 7600) for the added speaker into the power relay socket (C).

Attach the other end of this connecting cable to the added speaker (D).

6. Insert the AC plug of the power relay into an AC outlet.





YARD

BROWN YELLOW BLACK

Figure 1. Multiple Speaker Installation

SOCKET

029256

051060



	PARTS	LIST:	022202	POWER	RELAY	ASSEMBLY	
Insul Bushi		rain re	lief				055632

Bushing, strain relief

Grommet

Bushing, .196 x .312 x .325

Relay, single-pole double-throw, 1179 608+ Cable and Socket Assembly, 6-contact 130850 Socket, 6-contact (029546) Cable and Plug Assembly, 6-pin 136660 Socket, 6-contact 060459 Cable, AC, black 026823

Screw, sheet metal, 6 x 1/4. hex washer head (2) 026666 Screw, machine, 6-32 x 5/8 028001

Screw, sheet metal, 12 x 3/8, Phillips head . 020314 Washer, lock, 6 x 9/16 x .025