

LESLIE SPEAKER ACCESSORIES

Part No.	Description
010298	6 Conductor Bulk Cable for all models except 212S, 700, 770, 710, 760, 825, 910, 925, 950
010322	Cap with Cable Clamp for Cable Plugs & Sockets
015255	Remote Reverb Control for 147RV
017277	30' 6-Conductor Cable with Connectors on both ends
019133	9 to 9 Pin Cable Assembly, Custom Length
021600	30' for 710, 760, 770
021600	30'-9 Connector Cable with Connectors on both ends
021618	9 Conductor Bulk Cable
021709	Power Relay to connect 2 or more 102, 103, 212, 610, 600, 610, 700, 710, 760, 770, 825, 910, 925, 950 in tandem
022186	Brake for Models 125, 225, 145, 147, 147RV, 251, 245
022186	Brake for Models 125, 145, 147, 147RV, 225, 245
022871	Cable Assembly, 30'-for X-77P
023051	12 Hole Receptacle for X-77P on 9 Conductor Cable
023523	12 Pin Plug for X-77P on 9 Conductor Cable
028837	Receptacle for 9 Conductor Cable
028837	Receptacle for 9 Conductor Cable
029546	Receptacle for 6 Conductor Cable
029546	Receptacle for 6 Conductor Cable
031856	Power Relay for Multiple X-77P Installations
034256	Brake for Model 122
034488	Power Relay to connect 251 Cabinets in tandem
034496	Power Relay to connect 122, 125, 145, 147, 147RV, 225, 247 and 247RV in tandem
035659	6 to 5 Adapter
036632	6 to 6 Pin Cable Assembly, Custom Length
042127	Cover(s) Model 910, 925 (upper-lower units)
045393	Cover for 825
061721	Plug for 6 Conductor Cable
061879	Plug for 9 Conductor Cable
108030	Remote Rev/Aux Control for 910,925,950 (when 7270 Kit used)
113420	Cover for 760
137144	Vinyl Cover for Models 760, 815, HL-822
137330	11 Conductor for 130, 315, 415, HL-422, 540, 705, 715, 720, 815 HL-722, HL-822
137357	30' for 130, 315, 415, HL-422, 540, 705, 715, 720, 815, HL-722 and HL-822
137469	11 Pin 'Y' Adapter with Cable for multiple 315, 415, HL-422, 540, 705, 720, 815, HL-722, HL-822
137673	11 to 11 Pin
138157	9 to 11 Adapter with 11 Pin Cable for plug-in installation of 11 Pin Speakers
141543	Decorator Casters, set of four (4)
141726	8 ohm Crossover
141835	215 Control Center