

Leslie Models; Speakers, Belts and Motors

See tables at end of document to interpret letter & number codes

Source unknown. Not verified

Model 16

Speakers: I
Belts: B
Motor-fast: 1
Motor-slow: 3

Model 18

Speakers: L
Belts: B
Motor-fast: 1
Motor-slow: 3

Model 21H

Speakers: X,P
Belts: A,B
Motor-fast: ,1
Motor-slow: None

Model 22H

Speakers: O,P
Belts: A,B
Motor-fast: 1,1
Motor-slow: none

Model 22R

Speakers: O,P, with added 6 X
9"
Belts: A,B
Motor-fast: 1,1
Motor-slow: none

Model 25

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: none

Model 30

Speakers: X,P
Belts: A,B
Motor-fast: NLA
Motor-slow: none

Model 31H

Speakers: X,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 32

Speakers: X,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 44

Speakers: X,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 45

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 46

Speakers: X,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 47

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 50

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 51

Speakers: 2-F,O,P
Belts: A,B
Motor-fast: 1
Motor-slow: none

Model 55C

Speakers: O,F
Belts: B
Motor-fast: 1
Motor-slow: none

Model 60S

Speakers: I
Belts: none
Motor-fast: none
Motor-slow: none

Model 60M

Speakers: I
Belts: F
Motor-fast: none
Motor-slow: 5

Model 70S

Speakers: I
Belts: none
Motor-fast: none
Motor-slow: none

Model 70M

Speakers: I
Belts: F
Motor-fast: none
Motor-slow: 5

Model 77L

Speakers: F, N, P, H
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 77P

Speakers: F, N, P
Belts: A, B
Motor-fast: 1
Motor-slow: 2

Model 100GK/101GK

Speakers: F, O
Belts: B
Motor-fast: 1
Motor-slow: none

Model 101

Speakers: F, O
Belts: B
Motor-fast: 1
Motor-slow: none

Model 102

Speakers: F, O
Belts: B
Motor-fast: 1
Motor-slow: none

Model 103

Speakers: F
Belts: C
Motor-fast: 1
Motor-slow: 2

Model 105

Speakers:
Belts:
Motor-fast:
Motor-slow:

Model 110

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 112

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 114

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 116

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 120

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 122

Speakers: O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 122A

Speakers: O, P1
Belts: D
Motor-fast: U 6, L 7
Motor-slow:

Model 122A-T

Speakers: O, P1
Belts: D
Motor-fast: U 6, L 7
Motor-slow:

Model 122R or V

Speakers: O, P1
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 122RV

Speakers: E, O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 122XB

Speakers: O, P1
Belts: D
Motor-fast: U 6, L 7
Motor-slow:

Model 122XB-T

Speakers: O, P1
Belts: D
Motor-fast: U 6, L 7
Motor-slow:

Model 125

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 130

Speakers: B, M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 142

Speakers: O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 145

Speakers: O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 147

Speakers: O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 147A

Speakers: O, P1
Belts: D
Motor-fast: U 6, L 7
Motor-slow:

Model 147R or V

Speakers: O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 147RV

Speakers: F, O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 202

Speakers: O, Q
Belts: B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 202S

Speakers: O, Q, 6x9
Belts: B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 205

Speakers: F, O
Belts: B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 212S

Speakers: C, N, Q
Belts: B
Motor-fast: 1
Motor-slow: 3

Model 215

Speakers: C
Belts: B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 222

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 222R or V

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 222RV

Speakers: E, O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 225

Speakers: M
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 242

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 245

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 247

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 247RV

Speakers: F, O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 251

Speakers: 2-F,O,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 257

Speakers: O,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 258

Speakers: M, M, P
Belts:
Motor-fast: none
Motor-slow: none

Model 300

Speakers: J, O
Belts: B
Motor-fast: 1
Motor-slow: 3

Model 301

Speakers: F, J, O
Belts: B
Motor-fast: 1
Motor-slow: 3

Model 302

Speakers:
Belts:
Motor-fast:
Motor-slow:

Model 315

Speakers: A, C, E, K, P
Belts: D
Motor-fast: 4
Motor-slow: none

Model 322

Speakers:
Belts:
Motor-fast:
Motor-slow:

Model 330

Speakers: O,R
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 350

Speakers: J, O
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 351

Speakers: F, O, P
Belts: A, B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 415

Speakers: 2A,E,K,P
Belts: D
Motor-fast: 4
Motor-slow:

Model HL422

Speakers: 2A,E,K,P
Belts: D
Motor-fast: 4
Motor-slow:

Model 430

Speakers:
Belts: F, C
Motor-fast:
Motor-slow:

Model 450

Speakers:
Belts: F, C
Motor-fast:
Motor-slow:

Model 470

Speakers:
Belts: F, C
Motor-fast:
Motor-slow:

Model 515

Speakers: D, D
Belts:
Motor-fast:
Motor-slow:

Model 520

Speakers: H, N
Belts:
Motor-fast:
Motor-slow:

Model 540

Speakers: D, D
Belts:
Motor-fast:
Motor-slow:

Model 560

Speakers:
Belts:
Motor-fast:
Motor-slow:

Model 570

Speakers:
Belts:
Motor-fast:
Motor-slow:

Model 580

Speakers:
Belts:
Motor-fast:
Motor-slow:

Model 600

Speakers: F, N, P
Belts: A, B
Motor-fast: 1
Motor-slow: 2

Model 610

Speakers: F, O
Belts: D
Motor-fast: 1
Motor-slow: 3

Model 615

Speakers: D, V, K, P
Belts: D
Motor-fast: 4
Motor-slow:

Model 700

Speakers: 2-S, N
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 705

Speakers: 2-S,N
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 710

Speakers: 2-S,N,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 715

Speakers: 2-D,S,N,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 720

Speakers: 2-H,J,N,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 722 also HL722

Speakers: 2-D,S,N,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 723

Speakers:
Belts:
Motor-fast:
Motor-slow:

Model 730

Speakers: 2-H,M,N,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 740

Speakers: D, N, P, W
Belts: A, B
Motor-fast: 1
Motor-slow: 2

Model 750

Speakers: E, D, N, P
Belts:
Motor-fast: 4
Motor-slow:

Model 760

Speakers: N,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 770

Speakers: N,P
Belts: A,B
Motor-fast: 1
Motor-slow: U 2, L 3

Model 812

Speakers: O, P1
Belts: D
Motor-fast: U 6, L 7
Motor-slow:

Model 814

Speakers: O, P1
Belts: D
Motor-fast: U 6, L 7
Motor-slow:

Model 815

Speakers: 2-D,S,N,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 820

Speakers: L
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 822 also HL822

Speakers: 2-D,S,N,P
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 825

Speakers: L
Belts: B
Motor-fast: 1
Motor-slow: 2

M 830

Speakers: L
Belts: B
Motor-fast: 1
Motor-slow: 2

Model 840

Speakers: D, V, K, P
Belts: D
Motor-fast: 4
Motor-slow:

Model 860

Speakers: L,R
Belts: A,B
Motor-fast: 1
Motor-slow: 2

Model 900

Speakers: 2-F,N,P
Belts: ?,B
Motor-fast: 1
Motor-slow: 2

Model 910

Speakers: 2-F,N,P2
Belts: B, F
Motor-fast: 1
Motor-slow: 8

Model 925

Speakers: 4-F, T1, R1
 Belts: A,B
 Motor-fast: 1
 Motor-slow: 2

Model 950

Speakers: 4-L
 Belts: 4-B
 Motor-fast: 4-1
 Motor-slow: 4-2

TABLES**Belts**

- A) 522-045468
- B) 522-011700
- C) 522-020701
- D) 522-141182
- E) 543-111090
- F) 522-021048

Motors

- 1) 521-014019 Fast Motor
- 2) 521-012526 Slow Motor (up)
- 3) 521-014795 Slow Motor (down)
- 4) 521-141105 Motor (Tach)
- 5) 521-110720 Motor
- 6) 521-141105A Motor assy
- 7) 521-141105Ar Motor assy
- 8) 521-012534 Slow Motor
- 9) 521-014852 Slow Motor

Speakers

- A) 514-141153 2.52" - 8 ohm
- B) 514-137316 3"- 8 ohm
- C) 514-043125 6" x 9" - 8 ohm
- D) 514-138879 6" x 9" - 8 ohm
- E) 514-140431 6" x 9" - 8 ohm
- F) 514-031062 6" x 9" - 16 ohm
- G) 514-058214 6" x 9" - 16 ohm
- H) 514-137610 8" - 8 ohm
- I) 514-130540 10" - 4 ohm
- J) 514-017202 10" - 8 ohm
- K) 514-141069 12" - 4 ohm
- L) NLA 12" - 6 ohm
- M) 514-137348 12" - 8 ohm
- N) 514-031070 15" - 4 ohm
- O) 514-052308 15" - 16 ohm
- P) 514-140491 Treble Driver (3/4" Throat)
- P1) 514-059648 Treble Driver, ferro-fluid
- P2) 514-031260 Treble Driver
- Q) NLA 5" x 7" - 16 ohm
- R) NLA Treble Driver
- R1) 514-059981 Treble Driver 16 ohm
- S) 514-058214 PN: 514-031062 w/ cover
- T) NLA 15" - 4 ohm
- T1) 514-059973 15" 16 ohm
- U) NLA Treble Driver
- V) 014-056646 PN: 514-138879 w/ cover
- W) 014-056941 PN: ? w/ cover
- X) NLA 15" - 16 ohm Electro Dynamic. Replace with type "O" and place a separate choke of 2580 DCR in place of the field coil.